The Espresso Performance Monitor (EPM) package

Vincenzo Battista¹

¹École Polytechnique Fédérale de Lausanne (EPFL), Lausanne, Switzerland

A&S Week, Flavour Tagging Session, 24/01/2018





Outline

- Introduction
- 2 Example: $B^+ \to D^0 \pi^+$ calibration
- **3** Example: $B_s^0 \to D_s^- \pi^+$ calibration
- Example: use EPM models in your decay-time fit
- Conclusions and summary



Introduction

The Espresso Performance Monitor (EPM) package

Developed and (previously) maintained by Jack Wimberley (who left HEP).

Useful to:

- perform flavour tagging calibrations on both neutral and charged modes;
- evaluate tagging performance (ε_{tag} , ε_{eff} etc...);
- ullet combine taggers and add calibrated mistag (ω) in a tuple;
- produce publication-quality plots.

Motivations:

- standardise and simplify calibration process for analysts;
- new paradigm: a calibration for each analysis (no more global calibration from FT group!)

Theoretical framework described in:

J. Wimberley, Calibrating flavor tagging algorithms with binomial regression, LHCb-INT-2017-002 (link) A. Agresti, Categorical Data Analysis, John Wiley & Sons, Apr. 2014

Talk at the Statistics WG meeting: link

It's being documented also in the upcoming FT performance paper.

Twiki pages (link) with wide documentation and extensive details.

Flavour Tagging calibration: the "traditional" methods

Charged decay modes:

- E.g. $B^+ \to J/\psi K^+$ and $B^+ \to D^0 \pi^+$ for B^0 , $B_{s2}^* \to B^+ K^-$ for B_s^0 .
- Count true mistag fraction $\langle \omega_i \rangle$ in bins of η , then do linear fit.
- ⇒ systematics due to binning choice.

Neutral decay modes:

- E.g. $B^0 \to J/\psi K^*$ for B^0 , $B^0_s \to D_s \pi$ for B^0_s .
- Full time-dependent analysis with η as dimension, fit directly for $p_{0,1}$ and $\Delta p_{0,1}$.
- Alternative: time-dependent analysis in bins of η to obtain $\langle \omega_i \rangle$, then do linear fit.
- \Rightarrow systematics due to time-dependent analyses (resolution, acceptance, production asymmetries...) and eventually binning choice.

We have a continuous predictor (ω) and a binary output (right tag, wrong tag) \Rightarrow we better use a *binomial regression*

5 / 24

Vincenzo Battista (EPFL) FT meeting 24/01/2018

Binomial regression for charged modes

Assume a *charged* decay mode (no oscillations).

Calibrated mistag ω is a function of (uncalibrated) η , i.e. $\omega = \omega(\eta, \theta)$.

 θ is the set of *calibration parameters* to fit (aka p_i and Δp_i).

Probability that decay flavour = production flavour (i.e. correct tag): $\pi = \bar{\omega} = 1 - \omega$.

In terms of dilution $D = 2\bar{\omega} - 1$, we have $\pi = \frac{1+D}{2}$.

We can maximise the following log-likelihood:

$$L(\theta) = \sum_{k} \begin{cases} \pi_{k}(\theta) & \text{right tag} \\ 1 - \pi_{k}(\theta) & \text{wrong tag} \end{cases}$$

⇒ no binning effects!

⇒ using maximum likelihood estimator instead of least-squares.

Vincenzo Battista (EPFL) FT meeting 24/01/2018

Binomial regression for neutral modes

Probability π in the likelihood needs to take *oscillations* into account:

- Probability that tagged flavour = production flavour (right tag): $\bar{\omega} = 1 \omega$.
- Probability that production flavour = decay flavour (no oscillation):

$$p^{nomix} = \frac{1}{2} \left(1 + \cos \Delta mt \operatorname{sech} \frac{1}{2} \Delta \Gamma t \right) = \frac{1 + D^{nomix}}{2}$$

⇒ Probability that decay flavour = production flavour:

$$\pi = \bar{\omega}p^{nomix} + (1 - \bar{\omega})(1 - p^{nomix}) = \frac{1 + DD^{nomix}}{2}.$$

Dilution due to decay-time resolution:

$$p^{nomix} \rightarrow \int p^{nomix}(t')\mathcal{R}(t,t')dt = \frac{1+D^{res}D^{nomix}}{2} \Rightarrow \pi = \frac{1+DD^{res}D^{nomix}}{2}$$

Other effects (acceptance, production asymmetries \dots) are found to be negligible \Rightarrow see [LHCb-INT-2017-002] for an extensive treatment.

4□ > 4□ > 4 = > 4 = > = 9 < 0</p>

Simple linear model (so far the standard for all tagged analyses):

$$\omega(\eta) = \left(p_0 \pm \frac{\Delta p_0}{2}\right) + \left(p_1 \pm \frac{\Delta p_1}{2}\right) \left(\eta - \langle \eta \rangle\right).$$

EPM provides Generalised Linear Models (GLMs):

$$\omega(\eta) = g \left[g^{-1}(\eta) + \sum_{i} \theta_{i} f_{i}(\eta) \right]$$

g is the link function:

- inverse of CDFs (map $[-\infty, +\infty]$ to [0, 1]);
- EPM provides LOGIT, PROBIT or CAUCHIT (named after the parent PDF);
- from v0.7, also modified links to have ω in [0, 0.5] (RLOGIT, RPROBIT OF RCAUCHIT).
- the default is no link, i.e. the identity g = 1 (MISTAG)

$f_i(\eta)$ are basis functions:

- simple polynomials (POLY);
- more refined spline functions (NSPLINE, BSPLINE)
- they are orthogonal to minimise correlations among calibration parameters θ_i 's.

Install, compile and run

To build on lxplus:

```
git clone ssh://git@gitlab.cern.ch:7999/lhcb-ft/EspressoPerformanceMonitor.git cd EspressoPerformanceMonitor git checkout v0.7 git submodule update —init —recursive source setenv.sh cmake . make
```

The main executable you need is SimpleEvaluator, which takes an option file as argument:

./<path—to>EspressoPerformanceMonitor/bin/SimpleEvaluator my_options.py

9 / 24

Example: $B^+ \to D^0 \pi^+$ calibration

 $B^+ \to D^0 \pi^+$ calibration: introduction

Option file in options/example_BuD0piComplete.py

In this example, $B^+ \to D^0 \pi^+$ is divided in two subsamples. First half:

- calibrate OSComb and SSPionBDT using a GLM model;
- save calibrations (to XML files).

Second half:

- apply calibrations obtained before on OSComb and SSPionBDT, and evaluate performance;
- combine calibrated OSComb and SSPionBDT;
- calibrate combination and evaluate performance.

In total, the EPM has to be run twice (once for each subsample).

Vincenzo Battista (EPFL) FT meeting 24/01/2018 11 / 24

Input root file:

```
RootFile = "root://eoslhcb.cern.ch//eos/lhcb/wg/FlavourTagging/tuples/calibrat\
ion/data/BuDPi_stefania/Mergedfree_Bu2D0Pi_2011e2012_v33r9_ALL_newSStagger_cut\
sANDweights_LHCb_2014_ANA_003.root"
TupleName = "DecayTree"
Nmax = -1 # Events to run, -1 means all
```

Calibration model:

```
CalibrationMode = "Bu"
DoCalibrations = 1
Calibrationink = "RLOGIT"
CalibrationDegree = 2
CalibrationModel = "NSPLINE"
UseNewtonRaphson = 0 #use MINUIT
```

Plotting settings:

```
PlotLabel = "LHCb"
PlotTitle = 0
PlotExtension = ".pdf"
PlotStatBox = 0
```

Split data and save calibration:

```
Selection = "eventNumber%2==0"
SaveCalibrationsToXML = 1
```

Tagger branches, ID, weights, and combination:

```
BranchID
                     = "lab0 ID"
UseWeiaht
WeightFormula
                     = "N sia sw"
#Standard OS combination (OSe+OSmu+OSK+Vtx)
OS Combination Use
OS_Combination_Use = "lab0_TAGDECISION_OS"
OS_Combination_TypeDec = "Int_t"
OS_Combination_BranchProb
                             = "lab0_TAGOMEGA OS"
OS Combination TypeProb
                             = "Double t"
#SSPionBDT
SS PionBDT Use
SS_PionBDT_BranchDec
                         = "lab0 SS Pion DEC"
SS PionBDT TypeDec
                         = "Short t"
SS_PionBDT_BranchProb
                         = "lab0 SS Pion PROB"
```

= "Float t"

SS PionBDT TypeProb

EPM returns calibrated parameters and correlations. Everything is saved in the output XML file.

Example: OSComb.

```
-- LOGIT BASIS --
 -- N-SPLINE BASIS --
 NODES LOCATIONS:2.03e-06, 0.303, 0.673, 2.6
 BASIS ROTATION:
P \theta(x) = 1
P 1(x) = x -0.5166
P 2(x) = n2(x) -0.6662x +0.1899
P 3(x) = n3(x) -0.5636n2(x) +0.08349x -0.01318
 -- PARAMETER VALUES --
p0 = -0.046935 + -0.0063216
p1 = -0.09677 + -0.015257
p2 = 0.044698 + -0.046116
p3 = -5.3748 + -1.088
 -- PARAMETER DELTA VALUES --
\Delta p\theta = -0.072328 + -0.012643
\Delta p1 = 0.089606 + -0.030515
\Delta p2 = 0.027876 + -0.092233
\Delta p3 = -3.9018 + -2.1761
 -- CORRELATION MATRIX --
        pΘ
                          _{\mathbf{p1}}
                                                              р3
                                                                                                Δp1
                -0.00052038
                                   -0.0084483
                                                      -0.010726
                                                                        -0.017607
                                                                                         0.0046298
                                                                                                           0.0029438
                                                                                                                          -0.00083193
                                    -0.027099
                                                      -0.013888
                                                                       0.0046298
                                                                                        -0.0080058
                                                                                                            0.010852
                                                                                                                              0.004325
                                                      -0.017311
                                                                        0.0029438
                                                                                                          -0.0029852
                                                                                                                             0.0091045
                                                                                          0.010852
                                                                                                           0.0091045
                                                                                                                             -0.016075
                                                               1
                                                                     -0.00083193
                                                                                          0.004325
                                                                                       -0.00052038
                                                                                                          -0.0084483
                                                                                                                             -0.010726
                                                                                                           -0.027099
                                                                                                                             -0.013888
                                                                                                                             -0.017311
```


EPM provides different GOF tests for each calibration.

Example: OSComb.

```
-- OUTPUT CALIBRATION G.O.F. --
DEVIANCE = 144559.40
AIC = 144567.40
BIC = 144610.06
Brier Score = 36039.09
PEARSON X2 test = -0.2063
DEVIANCE G2 test is inapplicable to the logit link
CRESSIE-READ test = -0.21804
LCVHCH S test = 0.53387
```

Pearson, G2, Cressie-Read and ICvHCH tests output is *normally distributed* \Rightarrow expect 0 for perfect fit, 1 for 1 σ discrepancy etc...

More details in Twiki and LHCb-INT-2017-002.



Select other half of data, retrieve calibrations from previous step, combine calibrated taggers:

```
#Combine OS and SS
PerformOfflineCombination OSplusSS
OS Combination InComb
                                    = 1
SS_PionBDT_InComb
                                    = 1
#Take other half, select input calibration
Selection = "eventNumber%2!=0"
OS_Combination_CalibrationArchive = "../step1/OS_Combination_Calibration.xml"
SS_PionBDT_CalibrationArchive = "../step1/SS_PionBDT_Calibration.xml"
```

Output: now input calibration is applied on second 1/2 of data, then the performance is evaluated. From EspressoPerformanceTable.tex:

```
Tagger
                     \varepsilon_{\mathrm{tag}} (%)
                                                            \omega (%)
                                                                                                           \epsilon_{\rm eff} (%)
                 20.688 \pm 0.072
                                         38.883 \pm 0.023(\text{stat}) \pm 0.188(\text{cal})
                                                                                          1.023 \pm 0.006(stat) \pm 0.035(cal)
SS \pi BDT
OS Comb
                 36.906 + 0.086
                                         34.671 \pm 0.025(\text{stat}) \pm 0.132(\text{cal})
                                                                                          3.469 \pm 0.014(stat) \pm 0.060(cal)
```


Finally, OSComb+SSPionBDT is calibrated, and the performance is computed. From EspressoCalibratedPerformanceTable.tex:

 ω (%) Tagger ε_{tag} (%) $\epsilon_{\rm eff}$ (%) Comb 49.681 + 0.089 $35.220 \pm 0.022(\text{stat}) \pm 0.114(\text{cal})$ $4.341 \pm 0.015(\text{stat}) \pm 0.067(\text{cal})$

Vincenzo Battista (EPFL) FT meeting 24/01/2018

< □ > <圖 > < ≣ > < ≣ > <

Plots from OSComb+SSPionBDT combination.



Example: $B_s^0 \to D_s^- \pi^+$ calibration

$B^0 \to D_s^- \pi^+$ calibration: introduction

Option file in options/example_BsDspi.py

In this example, the SSKaonNNet is calibrated on $B^0 \to D_s^- \pi^+$ with a standard linear function.

A per-event time resolution model is used.


The gaussian width is obtained via a *linear calibration* of the decay-time error δ :

$$\sigma = A + \delta B$$

Moreover, the folded time-dependent asymmetry corrected for the dilution is plotted \Rightarrow should be $\cos(\Delta mt)$ within the uncertainties.

Relevant options:

```
UseTau = 1
UseTauErr = 1
ResolutionGaussian1_A = 1.0262e-05
ResolutionGaussian1_B = 1.28
TauUnits = "ns"
BranchTau = "lab0_TAU"
BranchTauErr = "lab0_TAUERR"
DrawOscillationPlots = 1
```



24/01/2018

Example: use EPM models in your decay-time fit

20 / 24

Introduction

lb-dev Urania/v7r0

Best practice in time-dependent analyses:

- find calibration $\omega(\eta)$ on control channel;
- include η as dimension in the fit;
- float calibration coefficients $(p_i, \Delta p_i)$ in the fit, apply Gaussian constraints.
- ⇒ uncertainties properly propagated to CPV/oscillation measurement!

It's now possible to use any GLM model from EPM in any RooFit-based fitter within Urania.

```
cd UraniaDev_v7r0
git lb-use Urania
git lb-checkout Urania/master FT/Espresso
git lb-checkout Urania/master <your-analysis-code>
```

How your RooFit script would look like:

eta_b (ω^B) and eta_bbar ($\omega^{\bar{B}}$) depend on eta (η) via the chosen GLM from EPM.

You can build your time PDF (ROOADSPdf) by including them ⇒ the calibration coefficients will appear as parameters in the fit.

Examples are in PhysFit/B2DXFitters.

Vincenzo Battista (EPFL) FT meeting 24/01/2018 22 / 24

Conclusions and summary

23 / 24

Conclusions and summary

The EPM became the standard tool for calibration and perfomance in the FT group.

We encourage analyst to use it! In case of questions/bugs/requests:

- FT WG mailing list: lhcb-phys-flavour-tagging@cern.ch
- EPM JIRA group (LHCBESPCAL)

Didn't have time to show all details.

Particularly relevant is the toy generator to check GOF and calibration parameters.

⇒ dedicated Twiki page here

Vincenzo Battista (EPFL) FT meeting 24/01/2018 24 / 24

24 / 24